

## Brake Hydraulic Components Regulator Booster

### Quick Data

#### WARNING

Friction materials such as brake and clutch linings or brake pads may contain asbestos fibers.

Do not create dust by grinding, sanding or by cleaning with compressed air.

Avoid breathing asbestos fibers and asbestos dust.


Breathing asbestos may result in serious diseases, such as asbestosis or cancer.

Breathing asbestos may cause severe injury and death.

### Index

- Brake booster 47.10
- Brake caliper
  - 1980–1985
  - Girling 47.5, 47.6
  - Teves 47.4, 47.6, 47.7
  - 1986–1987 47.7a, 47.7b
- Brake master cylinder 47.2, 47.3
- Brake pressure regulator 47.8
- 47.9
- Check valve 47.10
- Rear wheel cylinder 47.8

# 47 Brake-Hydraulic Components, Regulator, Booster




## WARNING

Brake fluid is poisonous

## CAUTION

When repairing brake master cylinder always use all parts in repair kit. Lubricate shaft of primary piston with silicone grease supplied in repair kit. Coat all other cups and pistons lightly with VW brake cylinder paste before installation



## WARNING

Never interchange primary and secondary cups. See cut-aways

## Note

When installing pistons, guide lips of cups/seals into housing with blunt tool

47-342


## 47.2 Brake master cylinder

## Note


DOT 4 brake fluid is now used in all production vehicles. The new fluid is recommended for all Volkswagen brake systems and is completely compatible with the previous DOT 3 fluid.

DOT 4 brake fluid has been phased into the spare parts program effective June, 1984.


The previous DOT 3 version brake fluid, Part No. ZVW 247 101, has been superseded to the new DOT 4 version, Part No. ZVW 239 102.



**Fig. 1** Circlip, removing/installing



**Fig. 2** Secondary cups, installing  
• always use fitting sleeve US 4425



**Fig. 3** Secondary piston, installing  
— hold brake master cylinder with opening facing down  
— guide lips of cups in carefully with blunt tool

## Note

After installing brake master cylinder bleed brake system (see page 47.8)



# 47 Brake-Hydraulic Components, Regulator, Booster

## WARNING

Brake fluid is poisonous

## CAUTION

Use all parts in repair kit. Coat seals and pistons lightly with VW brake cylinder paste or equivalent before installing



47-096

## Note



Cars may have either Teves or Girling calipers

## CAUTION

Use all parts in repair kit. Coat seals and pistons lightly with VW brake cylinder paste or equivalent before installing

## WARNING

Brake fluid is poisonous



47-251


## Note

Cars may have either Girling or Teves calipers


# 47 Brake-Hydraulic Components, Regulator, Booster

## Brake caliper, disassembling

### Work sequence




- pry dust cap out without scratching piston



- blow out piston with compressed air

### Note


Hold other piston with clamp US 1023/5. Place wooden block in caliper to prevent damage to piston




- remove seal without scratching cylinder

## Brake caliper, assembling


### Work sequence



- install seal
- lubricate piston and cylinder bore lightly with brake cylinder paste
- press in piston with installing clamp




- install dust cap by hand




- press dust cap with VW 442 against recess
  - piston is now fully seated
- Teves caliper, continue on next page

## Noise damping plates, installing (Teves caliper)

### Work sequence




- insert noise damping plates and check position of piston
  - recess in piston (arrows) point against direction of brake disc rotation when moving forward. Lugs on noise damping plates engage in recess on piston



- if necessary readjust position of piston by using turning pliers US 1023/2


# 47 Brake-Hydraulic Components, Regulator, Booster



47-428

## CAUTION


Use all parts in repair kit. Coat seals and pistons lightly with VW brake cylinder paste or equivalent before installing.




**Fig. 1** Caliper piston, removing with compressed air

**Note**


Place a wooden block in caliper to prevent damage to piston.



**Fig. 2** Piston seal, removing




**Fig. 3** Dust cap, installing



**Fig. 4** Piston and dust cap, installing

— insert inner lip of cap into groove in cylinder while holding piston



**Fig. 5** Piston, installing

— press piston as far as it will go

**CAUTION**


Outer lip of dust cap must slip into groove in piston.

# 47 Brake-Hydraulic Components, Regulator, Booster

## Rear wheel cylinder, disassembling/assembling

### CAUTION

When repairing wheel cylinders always use all parts of repair kit



## Brake system bleeding

### WARNING

Brake fluid is poisonous

### Bleeding sequence


- 1 — Right rear wheel cylinder
  - 2 — Left rear wheel cylinder
  - 3 — Right front caliper (upper screw)
  - 4 — Left front caliper (upper screw)
- after bleeding, fill reservoir to maximum mark

### CAUTION


Brake fluid must not come into contact with paint  
Brake fluid absorbs moisture from air and must be replaced every 2 years.  
Only use new DOT 3 or DOT 4 brake fluid according to SAE recommendation J 1703 and conforming to MOTOR VEHICLE SAFETY STANDARD 116. Do not add or mix DOT 5 silicone type brake fluid with brake fluid in car as severe component corrosion may result. Such corrosion could lead to brake system failure

## Brake pressure regulator, checking


### Work sequence




- lift vehicle with hoist
- go to next page




— connect gauge US 1016 to front brake caliper



— connect gauge US 1016 to rear wheel cylinder  
— bleed both gauges  
— depress brake pedal several times



— remove nuts holding regulator and remove regulator from studs  
— press brake pedal until both gauges read 50 bar (725 psi)



— tilt regulator forward  
• angle  $\alpha = 30^\circ$

## CAUTION

Do not damage brake lines

- increase pressure on brake pedal until gauge connected to front brake caliper reads 100 bar (1450 psi)
  - pressure at gauge connected to rear wheel cylinder must read 55–65 bar (798–943 psi)
- if **NO**, replace brake pressure regulator
- reinstall regulator
- disconnect gauges
- bleed brakes


# 47 Brake-Hydraulic Components, Regulator, Booster

## Brake booster, checking

- depress brake pedal firmly several times with engine off to exhaust vacuum in system
- depress pedal with medium pressure and hold
- start engine
  - if brake booster is working properly, pedal will fall slightly and then hold


### CAUTION

Do not repair brake booster.  
If necessary, replace



## Check valve, checking (installed in vacuum hose)


### Work sequence



- remove valve (arrow) from hose
- blow through valve in direction of arrow (on housing)
  - air must pass through valve
- blow through valve in opposite direction
  - no air must pass through valve

Quick Data	Index
	<ul style="list-style-type: none"><li>—Column 48.2<ul style="list-style-type: none"><li>switches 48.2</li></ul></li><li>—Lock assembly 48.3</li><li>—Manual steering drive/ gear 48.4</li><li>—Power steering system<ul style="list-style-type: none"><li>checking for leaks 48.7</li><li>gear assembly 48.10, 48.11</li><li>hydraulic fluid (ATF) filling/ bleeding 48.7, 48.8</li><li>hydraulic fluid (ATF) reservoir 48.7</li><li>suspension changes 48.6</li><li>system layout 48.6</li><li>system pressure 48.7</li><li>technical data 48.6</li></ul></li><li>—Power steering pump<ul style="list-style-type: none"><li>pressure, checking 48.7</li><li>removing/installing 48.15</li><li>repairing 48.16, 48.17</li></ul></li><li>—Pressure flow limiting valve 48.17</li><li>—Tie rods 48.4, 48.5</li><li>—Wheel 48.2, 48.3</li></ul>


# 48 Steering





**Fig. 1 Steering lock housing, removing**

— pull off steering lock housing together with spacer sleeve




**Fig. 4 Spacer sleeve, installation dimension**

A = spacer sleeve


a = 41.5 mm (1.634 in.)

b = 2-4 mm (3/32-5/32 in.)



**Fig. 2 Steering lock housing / spacer sleeve, installing**

— when installing spacer sleeve, clamp steering column at top and bottom



**Fig. 5 Upper steering column/column tube, assembling**



**Fig. 3 Steering lock housing/spacer sleeve, installing**

— note dimension a, see Fig. 4


# 48 Steering

## WARNING

Do not weld or straighten any steering components. Replace if damaged


## CAUTION

Only use special steering gear grease Part No. AOF 063 000 04 to lubricate steering gear




48-329


## 48.4 Tie rods Steering drive/gear




**Fig. 1 Tie rod, removing**  
— press tie rod off steering knuckle



**Fig. 2 Tie rod, unlocking**  
— unlock tie rod (arrow) from steering gear



**Fig. 3 Tie rod, locking**  
— tighten tie rod to 70 Nm (51 ft lb) and lock



**Fig. 4 Bushing, removing/installing**  
— press out or in as shown  
• flat surface of bushings must be vertical when rack is installed in vehicle

# 48 Steering


## Suspension changes for power steering

- steering knuckles are different
- coupling disc (between steering gear pinion and transfer gear connecting shaft) has been replaced by universal joint

## Technical data for power steering

Lubricant capacity 1.25L (1.3 US qt)  
Type ATF Dexron®  
System pressure (at idle) 115-120 bar/1668-1740 psi

## Power Steering System Layout




48—525

## Steering System, checking for leaks (engine running)

- rotate steering wheel lock to lock and hold in position (no longer than 5 sec.)
- check all line connections and tighten if necessary
- if leak occurs at steering pinion, replace valve housing seal, pinion housing seal, and o-ring between valve housing and pinion housing
- if steering rack seals are leaking (pull boot off steering gear to check), disassemble steering gear and replace all sealing components (all parts marked with asterisk, see pages 48.10 and 48.11)
- check power steering pump for leaks

## Power steering pump pressure, checking



- connect pressure gauge US 1074 B between pressure line and valve housing (valve in open position)

### Note


When installing gauge, turn it upwards as far as possible.

- start engine and run at idle
- top up ATF in reservoir if necessary
- close valve (no longer than 5 sec.)
- read pressure
  - 115-120 bar (1668-1740 psi)
- if pressure differs, check pressure/flow limiting valve, see page 48.17
- if pressure/flow limiting valve OK, replace power steering pump

## Power steering system, filling/bleeding

### CAUTION

If ATF level is too low, always check power steering system for leaks. Always fill and bleed power steering system with ATF after opening system for repair. Do **not** reuse fluid which has been drained. Always replace power steering filter in reservoir when changing ATF.



Power steering reservoir

# 48 Steering

---

- fill power steering reservoir to **MAX** with ATF
- lift front of vehicle
- with engine **off**, rotate steering wheel from lock to lock
- top up reservoir to **MAX** mark
- start engine briefly several times (switch **OFF** immediately after engine starts)
- add ATF until level is maintained at **MAX** mark

## CAUTION

Do not allow reservoir to be pumped dry.

- when ATF level no longer drops, start and run engine
- rotate steering wheel lock to lock several times

## Note


Do not use more force on steering wheel than necessary to turn wheel.


- add more ATF if level drops below **MAX** mark
- check that no bubbles appear in reservoir and level remains constant

## Steering gear assembly, repairing

### Note

When repairing, replace all components marked with an asterisk.  
Coat all sealing components with ATF when installing






## Note

When repairing, replace all components marked with an asterisk.  
Coat all sealing components with ATF when installing


48-503



**Fig. 1 Threaded rings, removing/installing**

**Note**

Be sure to install work cylinder in proper position.  
Check dimensions **a** and **b** (see page 6)  
— after tightening to proper torque,peen ring in housing




**Fig. 2 Sealing tube, removing from rack**

- clamp steering rack in vise using soft jaw covers to protect rack teeth
- remove work piston from rack

**CAUTION**


Do not damage rack surface while removing/installing circlips.

- remove tube from rack with swift motion
  - rack seal in tube will be ruined



**Fig. 3 Rack seal in tube, removing**

- **A** = extractor Kukko No. 21/4




**Fig. 4 Rack seal in tube, installing**

- clamp steering rack in vise using soft jaw covers to protect rack teeth
- install sealing tube over rack
- install support ring in sealing tube
- slip seal onto rack using locally obtained seal protector **A** (thin plastic sheet, heavy paper)


**Note**

Open side of seal faces up.

- after seal and protector have been slid past circlip grooves of rack, remove seal protector




**Fig. 5 Rack seal in tube, pressing in**



**Fig. 8 Pinion housing seal, pressing in**


**Note**

Open side of seal faces tool




**Fig. 6 Rack seal/bearing ring in end housing, removing**

- A = extractor Kukko No. 21/4



**Fig. 9 Valve housing needle bearing, removing**


- A = extractor US 1088




**Fig. 7 Rack seal in end housing, pressing in**

**Note**

Open side of seal faces tool.




**Fig. 10 Valve housing seal, pressing out**



**Fig. 11 Valve housing seal/needle bearing, pressing in**

- imprinted side of needle bearing toward tool



Power steering pump,  
removing/installing


48-502

## Power steering pump, repairing

### Note


When repairing pump, replace all parts marked with an asterisk.  
Coat all sealing components with ATF on installation.





**Fig. 1** Pressure/flow limiting valve retainer, installing

- install angled ends of retainer in housing slot
- press down angled ends with screwdriver



**Fig. 2** Rotor and shaft, removing/installing

#### Note

Rotor and shaft must be removed from housing to replace pump shaft seal.

- press rotor down
- remove circlip from groove (arrow)
- after installing rotor and shaft, secure circlip by pulling rotor up

#### Note

Circlip must fit properly in groove and be secured by rotor.

### Pressure/flow limiting valve, checking

#### Note

Incorrect functioning of pressure/flow limiting valve causes periodic lack of steering assistance.

- check valve and housing bore for wear
  - valve drillings must be completely clear of any dirt or restriction
  - valve must move freely in housing bore
- if maximum pump pressure is not obtained after checking pressure/flow limiting valve, replace complete power steering pump