


# Clutch Controls

Quick Data	Index	
clutch adjustment ..... not adjustable pressure plate/flywheel ..... 25 Nm/18 ft lb	<b>Water-Cooled Gasoline</b> <ul style="list-style-type: none"> <li>— Brake/Clutch fluid reservoir 30.3</li> <li>— Clutch assembly 30.4               <ul style="list-style-type: none"> <li>controls 30.2</li> <li>diaphragm spring 30.6</li> <li>disc 30.7</li> <li>hydraulic system 30.2</li> <li>pressure plate 30.6, 30.7</li> </ul> </li> <li>— Release shaft bushing 30.3</li> <li>— Roll pin 30.3</li> </ul> <b>Diesel</b> <ul style="list-style-type: none"> <li>— Brake/Clutch fluid reservoir 30.3</li> <li>— Clutch assembly 30.5               <ul style="list-style-type: none"> <li>controls 30.2</li> <li>diaphragm spring 30.6</li> <li>disc 30.7</li> <li>hydraulic system 30.2</li> <li>pressure plate 30.6, 30.7</li> </ul> </li> <li>— Release shaft bushing 30.3</li> <li>— Roll pin 30.3</li> </ul>	<b>Air-Cooled</b> <ul style="list-style-type: none"> <li>— Brake/Clutch fluid reservoir 30.3</li> <li>— Clutch assembly 30.4               <ul style="list-style-type: none"> <li>controls 30.2</li> <li>diaphragm spring 30.6</li> <li>disc 30.7</li> <li>hydraulic system 30.2</li> <li>pressure plate 30.6, 30.7                   <ul style="list-style-type: none"> <li>modification 30.6, 30.7</li> </ul> </li> </ul> </li> <li>— Release bearing 30.7</li> <li>— Release shaft bushing 30.3</li> <li>— Roll pin 30.3</li> </ul>

# 30 Clutch, Controls




30-072

## 30.2 Clutch hydraulic system Clutch controls

4-speed 091-091/1

5-speed 094

A-2




**Fig. 1** Roll pin, installation position

- roll pin must be engaged in groove (arrow) on side of bracket


## CAUTION

Brake fluid must not come into contact with paint.  
Brake fluid absorbs moisture from air and must be replaced every 2 years.  
Only use new unused DOT 3 or DOT 4 brake fluid according to MOTOR VEHICLE SAFETY STANDARD 116. Do not add or mix DOT 5 silicone type brake fluid with brake fluid in car, as severe component corrosion may result. Such corrosion could lead to clutch and brake system failure




**Fig. 2** Brake/clutch fluid reservoir, filling

- grasp two recesses on back of dashboard cover and pull up
- fill with brake fluid (see above caution) until level is between "MAX" and "MIN"
- replace cover by inserting front edge first then press cover down firmly



**Fig. 3** Release shaft bushing, removing




**Fig. 4** Release shaft bushing, installing

— drive in flush

# 30 Clutch, Controls

## Note

Only transmission must be removed for clutch repairs



## WARNING

Friction materials such as brake and clutch linings or brake pads may contain asbestos fibers.

Do not create dust by grinding, sanding, or by cleaning with compressed air.


Avoid breathing asbestos fibers and asbestos dust.

Breathing asbestos may result in serious diseases, such as asbestosis or cancer.


Breathing asbestos may cause severe injury and death.

## Note

For clutch repairs, transmission must be removed




# 30 Clutch




**Fig. 1 Clutch pressure plate, Gasoline removing/installing**

- attach flywheel retainer VW 215c
- mark position of pressure plate on flywheel (arrow)
- loosen bolts diagonally




**Fig. 2 Clutch assembly, Diesel removing/installing**

- change retainer over when removing




**Fig. 3 Clutch diaphragm spring, checking fingers**

- scores (arrows) up to depth of 0.3 mm (0.012 in.) are OK



**Fig. 4 Clutch pressure plate, 228 mm (9 in.) dia. (modification only for air-cooled vehicles)**

distance a between fingers:  
was = 55mm (2 3/16 in.) dia.  
is now = 46mm (1 13/16 in.) dia.




**Fig. 5 Production release bearing, air-cooled engines**

- contact surface diameter is 46 mm (1 13/16 in.)

## 30.6

Clutch disc  
Clutch pressure plate  
Clutch diaphragm spring

4-speed 091-091/1 5-speed 094



30-236

**Fig. 6 Replacement release bearing, air-cooled engines**

### Note


Release bearing with wider contact surface (arrow) is the only bearing available as spare part. This release bearing will work with either old or new type pressure plates.

### Engine replacement

If exchanging engines, be sure that wider-contact-surface release bearing is used if pressure plate is of older type [where a, Fig. 4, = 55 mm (2 3/16 in.) dia.]

### CAUTION


**Do not** install release bearing having narrow contact surface [46 mm (1 13/16 in.) dia.] together with short-fingered pressure plate [a = 55 mm (2 3/16 in.) dia.]



30-032

**Fig. 7 Clutch pressure plate, checking**


- check straps (black arrows) between plate and cover for cracks and tightness of rivets (white arrows)
- clutches with loose or damaged rivets must be replaced



30-006

**Fig. 8 Clutch pressure plate, checking**

- check for cracks, burn marks and wear
- inward taper: 0.3 mm (0.012 in.) max.



30-008

**Fig. 9 Clutch disc, checking**

- check runout: 0.5 mm (0.020 in.) max.
- measured 2.5 mm (3/32 in.) from edge of disc
- check lining and splines for wear and rivets for tightness
- when installing, lubricate splines with MoS<sub>2</sub> powder