

Air heaters B 1 L C / D 1 L C



Technical Description
Operating Instructions
Installation Instructions

® Eberspächer

J. Eberspächer
Eberspächerstr. 24
D-73730 Esslingen
Telefon (zentral)
(07 11) 9 39-00
Telefax
(07 11) 9 39-05 00

Air heaters of independent,
B 1 L C for Gasoline
D 1 L C for Diesel fuel



Cat. No.
Basic heater with standard equipment
Heating capacity control: High – Medium – Low

B 1 L C – 12 Volt	20 1719 05 00 00
D 1 L C – 12 Volt	25 1835 05 00 00
D 1 L C – 24 Volt	25 1836 05 00 00

Basic heater with standard equipment
Heating capacity control: High – Medium – Low – Off

D 1 L C – 12 Volt	25 1830 05 00 00
D 1 L C – 24 Volt	25 1831 05 00 00

Specifications

Heating medium	Air		
Heating capacity control	High	Medium	Low
Heating capacity ¹⁾	1800	1200	850 W
Hot air throughput without counterpressure ¹⁾	110	70	70 kg/h
Fuel consumption ¹⁾ D 1 L C	0,21	0,14	0,10 l/h
B 1 L C	0,24	0,16	0,12 l/h
Fuel – B 1 L C	Gasoline		
Fuel – D 1 L C	Diesel fuel (commercially available)		
Rated voltage	12 V or 24 V respectively		
Operating range			
Minimum voltage ²⁾	10 V or 20 V respectively		
Maximum voltage ³⁾	14 V or 28 V respectively		
Electric power consumption ¹⁾			
at start	12 V = 245 W 24 V = 265 W		
in operation	High	Medium	Low
	25	15	15 W

Ventilation operation	possible with suitable circuits
Radio interference	remote, additional suppression measure possible
Weight	approx. 3.5 kg

- ¹⁾ at rated voltage.
- ²⁾ an undervoltage safety device built in into the control unit switches off the heater at around 10.5 V or 21 V respectively.
- ³⁾ an overvoltage safety device built into the control unit switches off the heater at around 15 V or 30 V respectively.

All values ± 10 %

Contents

Scope of delivery/Cat. Nos.	2,3
Official regulations/General	4
Installation instructions	5–15
Typical installation/installation position	5
Installing the heater	6
Principal dimensions	6
Permissible installation positions/	
Fastening methods	6,7
Running the heating air	7
Running the combustion air	8
Running the exhaust	8
Fuel supply	9,10
Fuel at low temperatures	10
Electrics/wiring diagrams	11–13
Function description	14,15
Operation	16

Scope of delivery

Item	Stk.	Designation / Cat. No.
1 - 6	1	Basic heater with standard equipment
		Regulation: High / Medium / Low
		B 1 L C – 12 V 20 1719 05 00 00
		D 1 L C – 12 V 25 1835 05 00 00
		D 1 L C – 24 V 25 1836 05 00 00
		Regulation: High / Medium / Low / Off
		D 1 L C – 12 V 25 1830 05 00 00
		D 1 L C – 24 V 25 1831 05 00 00

The standard equipment comprises:

1	1	Basic heater (not available alone)
		B 1 L C – 12 V 20 1719 01 00 00
		D 1 L C – 12 V 25 1835 01 00 00
		D 1 L C – 24 V 25 1836 01 00 00
		D 1 L C – 12 V 25 1830 01 00 00
		D 1 L C – 24 V 25 1831 01 00 00
2	1	Control unit
3	1	Holder for control unit
4	1	Metering pump with built-in fuel filter
5	1	Current regulator
6	1	Cap

To be ordered in addition:

7	1	Operating unit
		12 V 25 1767 71 00 00
		24 V 25 1768 71 00 00
–	1	Universal installation kit
		25 1830 80 00 00
		(Cable harness heater to control unit 600 mm long)

Additional parts, optional, to be ordered extra

Cat. No.

Heater timer	12 V – 22 1000 30 10 00
	24 V – 22 1000 30 11 00



Fasteners	25 1482 70 01 00
(only necessary when installed with surround)	

Temperature sensor, external	25 1774 89 03 00
------------------------------	------------------



Cable for temperature sensor	25 1482 89 40 00
4 m long	


Cable for heater – control unit	22 1000 30 24 00
2 m long	

Please note:

The external temperature sensor must be used in fresh-air operation. It is used instead of a room thermostat for temperature control. Other room thermostats must not be used for D1L C heaters. For operation see page 11, for connection the wiring diagrams on pages 12/13.

See Additional Equipment Catalog for further accessories.

Scope of delivery



Please note:

The installation kit contains one flat fuse and two flat fuse housings.
Both flat fuse housings can be assembled and then attached with one screw.
Insert the flat fuse.
One flat fuse housing remains free.

parts without item number
= universal installation kit

Approval, official regulations, general

1. For vehicles registered in West Germany (subject to the road traffic regulations StVZO), the heaters are approved by the Federal Motor Vehicle Office and receive the official test symbol B 1 L C $\mathcal{W}\mathcal{W}$ S 237 or D 1 L C $\mathcal{W}\mathcal{W}$ S 221 indicated on the name plate.

The year of first operation is a requirement of German approval not representing a model number.

2. If the heater is installed in special-purpose vehicles (e. g. vehicles transporting dangerous cargoes), the regulations applicable to such vehicles must be observed.
3. The heater must not be operated in closed rooms, e. g. garages.

The heater must always be switched off when the petrol tank is to be filled.

4. The heaters must be installed by a workshop approved by the manufacturer and in compliance with the installation instructions.
5. The heaters may only be used for the purpose specified by the manufacturer and in compliance with the operating instructions supplied with every heater.

Operating the heater is not permitted where inflammable vapours or dust can build up (e. g. near fuel, coal or sawdust stores, grain silos etc.).

Spray cans and gas cartridges in the vehicle must be kept out of the heating air current.

6. The proposed installations in the installation instructions are only examples. Other installation locations are also permissible, provided they comply with the general installation requirements: the manufacturer should be consulted if necessary. In all other respects, differences from the installation instructions, particularly with regard to wiring (wiring diagrams), fuel supply, combustion air and exhaust ducts, and use of operating and control elements not supplied by the manufacturer, are only permissible with the written approval of the manufacturer. Failing that, the manufacturer's warranty is null and void for the entire heater system, as is the general operating permit.

7. Every combustion process generates exhaust gas, which has toxic constituents. Because of this and the high temperatures generated, the exhaust duct must comply without fail with the installation instructions. Failure to comply with the instructions or operation of the heater in closed rooms (garages) harbours the risk of poisoning.

8. When the heater or the heating system is damaged, an authorized workshop must be called in to repair the damage in an expert manner and using genuine spare parts.

Makeshift repairs (on one's own initiative) or the use of non-genuine spare parts are dangerous, and therefore not permitted. When carried out in cars, they invalidate the general design approval of the heater and consequently the general permit of the vehicle.

9. The warranty conditions are set forth in the heater booklet given to you by the after-sales service workshop when the heater is installed. Only our warranty conditions shall apply.
10. Further information on installation (e. g. in boats and ships) is available on request from the manufacturer.

Factory plate

The factory plate is fastened to the basic heater.

J. EBERSPÄCHER ESSLINGEN MADE IN W. GERMANY	
Heizgerät Typ	
Ausführung	
Fabrik Nr.	
Prüfzeichen	$\mathcal{W}\mathcal{W}$ S
Brennstoff	
Elektr. Werte	
Wärmestrom	
Betriebsüberdruck	
Erste Inbetriebnahme	
93	94 95

Year commissioned

Type approval has been applied for at the Federal Motor Vehicle Office for vehicles registered in West Germany.

Installation Instructions



The suggestions put forward in these installation instructions are only examples. Possibilities other than those illustrated (e. g. in the selection of the installation position or means of running air) are also permissible provided they meet the requirements of the West German road traffic regulations (StVZO), and if necessary after consultation with the manufacturer.

Typical installations/installation position

in the cab of the excavator



in the truck cab

1. on the rear panel of the cab
2. under the driver's seat



inside a passenger car

1. under the back seat, inside or underfloor
2. in front of the passenger seat
3. on the center console



Installing the heater

The B1LC/D1LC heaters are suitable and approved for installation in vehicle areas used by persons. Installation in the driver or passenger areas of motor buses* is not permitted.


In the case of installation in areas used by persons, the exhaust, combustion air and fuel lines must not have detachable connections inside these areas, and must be laid splash water proof at the penetrations to the outside.

For this reason the heater must be fitted by its base on an outside panel of the vehicle or on the vehicle floor, using the seal seated on the base.


The factory plate must be clearly visible when the heater is installed. If necessary a second plate (duplicate) with the same information as the original can be affixed to a point on the heater clearly visible after installation or to a cover located in front of the heater. A second plate is not necessary if the original is visible after removal of a cover without the aid of tools.

* Vehicles with more than 9 seats.

Principal Dimensions



Permissible installation positions



The heater should be installed in the standard position as shown. See sketch for maximum permissible deviations.

Please consult the manufacturer if further differences are required.

During starting and thermostatic operation a heater installed in the standard position may deviate, due to the inclination of the vehicle during motion, up to $\pm 15^\circ$ in both axes from the standard position.


Continuous heating operation after starting is possible at a deviation of up to $\pm 30^\circ$ from the standard position. With deviations exceeding $\pm 30^\circ$ reliable heating operation is no longer possible. However, this does not lead to damage of the heater if the changes in the operating position are only for brief periods.

Important: the plug connection must always point upwards.



Fastening to the vehicle wall/floor



Make penetrations in accordance with the template pattern.



The 10.5 mm dia. hole for the metering pump/control unit cable is not included in the template pattern and must be drilled to suit the installation method.


The mating surface for the heater base must be smooth. To drill the penetrations and if necessary to smooth the mating surface a special tool is available from the manufacturer under Cat. No. 99 1201 46 53 29.

Special tool




* This must be kept free.

If the mating surface sheet is too thin (criterion: thinner than 1.5 mm), a reinforcing plate, Cat. No. 20 1577 89 00 03 can be installed additionally on the outside.



Running the Heating Air – Parts for running the heating air included in the scope of delivery for the universal installation kit



- 1 Protective grid
- 2 Reducing piece
- 3 Hose clip, dia. 50 mm to dia. 70 mm

- 4 Flexible pipe, dia. 60 mm (1 m + 1 m)
- 5 Air outlet, rotatable
- 6 Connection piece, dia. 60 mm


When checking an installation the average output temperature should not significantly exceed 100°C at the output point with an intake temperature of 20°C. This will ensure that the safety thermal cutout switch will not respond under normal operating conditions.

Heating air intake openings shall be arranged in such a manner that exhaust from the vehicle's engine and from the heater cannot be expected to be sucked in under normal operating conditions, and the heating air cannot be contaminated.

When operating as a recirculating heater, locate the inlet for the heating air in such a way that the outflowing hot air cannot be sucked directly in again.

Running the combustion air/Running the exhaust

Permissible diameters, lengths, bends of combustion air and exhaust lines.



Permissible diversions – exhaust line: max. 180°; combustion air line: max. 180°.

The scope of delivery includes a flexible exhaust pipe, 24 mm internal dia., 1 m long. This can be shortened as required. For longer pipes see the Additional Equipment Catalog.

The scope of delivery includes a flexible combustion air pipe, 20 mm internal dia., 1 m long. This can be shortened as required. For longer pipes see the Additional Equipment Catalog.

Additional noise suppression is possible by installing an exhaust silencer or combustion air silencer (see Additional Equipment Catalog). The permissible overall length, including silencer, remains unchanged.

The combustion air must be sucked in from the outside, not from the passenger compartment or trunk.

Do not install the intake opening facing the slipstream, but run it in such a manner that dirt and snow cannot enter and that any water which does enter can flow out.

Exhaust lines must not project beyond the sides of the vehicle. They must be laid either with a slight slope or with 5 mm dia. holes at the lowest points for draining off condensate.

Arrange the exhaust outlet and the combustion air opening such that the exhaust cannot be sucked back in directly.

The exhaust outlet must be on the outside. Exhaust lines must be laid in such a way that neither the penetration of exhaust into the vehicle interior nor the intake of exhaust through the vehicle or heater blowers need be expected¹⁾, and that the operation of essential vehicle parts is not affected (ensure adequate clearance). Place the outlet opening of the exhaust line in such a way that it cannot be clogged by dirt and snow and that any water which does enter can run off. Do not install facing the slipstream.

¹⁾ This requirement is deemed met when the outlet of the exhaust pipe points upwards or to the side, or – when the exhaust is run under the vehicle floor – is positioned close to the side or rear edge of the cab or vehicle.


Fuel supply

Divergences from the instructions set forth here are not permitted, as they can lead to malfunctions.

1. For cars with diesel engines, and for cars with petrol engines having mechanical pump.

Fuel tapped from the fuel supply line to the engine.

Precondition: The fuel line from the fuel tank to the engine must be leak-free, so that there is no break in the fuel column when the engine is not running.




Dimension a = max. 2 m with petrol
max. 5 m with diesel
Dimension b = 50 mm
Dimension c = max. 300 mm
Dimension d = max. 4 m with petrol
max. 6 m with diesel

2. For cars with petrol injection engines and for trucks with diesel engines.

Tapping fuel from the supply line downstream of the delivery pump is prohibited in cars, since pressures of up to 10 bars can occur.

The following possibilities are available:

2.1 Tapping fuel – where possible – using a separate riser pipe, fitted to the fuel tank fitting in the case of cars, and directly into the fuel tank in the case of trucks.



Dimension a = max. 2 m with petrol
max. 5 m with diesel
Dimension d = max. 4 m with petrol
max. 6 m with diesel

2.2 If it is not possible to fit a separate riser pipe in the case of cars with petrol injection engines, the return line can be tapped using a T-piece.

Conditions:

1. There must be no valve installed in the return line of the fuel tank.

2. The pressure in the return line must not exceed 2 bars. For pressures greater than 0.3 bars and up to 2 bars, a pressure reducing valve (additional equipment Cat. No. 20 1645 89 30 00) must be provided upstream of the metering pump.

2.3 If it is not possible to fit a separate riser pipe in the case of trucks with diesel engines, the fuel supply line can be tapped (as shown under 1.).

1 Fuel tank (vehicle tank or separate tank)

2 Fuel branch

3 Fuel hose, internal dia. 5 mm
Cat. No. 360 75 350

4 Fuel pre-filter
(only necessary when contaminated fuel is used)
Cat. No. 25 1226 89 00 37

5 Fuel metering pump (15° to vertically upwards)

6 Fuel hose, internal dia. 3.5 mm
Cat. No. 360 75 300

7 Fuel pipe, plastic, internal dia. 1.5 mm
Cat. No. 090 31 118


For D 1 LC also permissible: Fuel pipe, plastic,
internal dia. 2 mm, Cat. No. 090 31 117

8 Riser pipe, internal dia. 2 mm
external dia. 4 mm } Cat. No.
9 Connection socket } 20 1645 89 35 00
external dia. 4 mm

10 Riser pipe, internal dia. 2 mm Cat. No. 25 1226 89 50 00
external dia. 6 mm

11 Fuel pipe, internal dia. 2 mm
Cat. No. 090 31 125

3. Permissible suction and pressure heads for installation per 1. and 2.; permissible positioning of metering pump



Supply pressure from tank to metering pump:
e = max. 3000 mm suction head:
tank at zero pressure

f = max. 500 mm with gasoline
f = max. 1000 mm with diesel oil

Check whether tank ventilation works properly
intake from tank when underpressure occurs during
(operation valve 0.03 bar in tank cap)
f = max. 150 mm with gasoline
f = max. 400 mm with diesel oil

Pressure head metering pump to heater:
g = max. 2000 mm

Fuel line metering pump to heater should not have a slope
if at all possible.

2. Important


Protect fuel lines, filter and metering pump from overheating; do not install near silencers and exhaust pipes. Temperatures above 30°C lead to gas bubbles and problems with gasoline.

When installing the fuel line, fuel filter and fuel metering pump near the rear axle, be sure to take the spring deflection of the rear axle into consideration.

Cut fuel tubes and pipes to length only with a sharp knife. Cuts may not be indented and must be burr-free.

For connection of the fuel branches, always use rubber tubing, never plastic pipe.

Fuel pipes connected by means of a fuel tube.
Fuel pipe sections must abut.



D1LC
Fuel grades/Fuel at low temperatures

The heater can take without problem the same fuel you use in your tank. In the USA diesel fuel no. 1 and no. 2. Admixture of used oil is not permitted.

The refineries automatically adapt their fuels to normal winter temperatures (Winter Diesel).

Therefore difficulties can only arise at extremely low temperature (as in the engine – see the vehicle’s instruction manual).

If the heater is operated from a separate tank, the following rules must be observed: at temperatures above 0°C any type of diesel fuel can be used.

If no special cold-weather diesel fuel is available at low temperatures, mix kerosine or gasoline according to the adjacent table.

Temperature	Winter diesel oil	Additive
From 0°C to –15°C**	100%	–
From –15°C to –25°C	50%	50% kerosine or gasoline
From –25°C to –40°C	–	100% kerosine*
* or special winter diesel oils		
** or in accordance with fuel manufacturer’s specifications		

The fuel line and the fuel pump must be filled with new fuel by operation for 15 minutes.

Fuel for special cases


In special cases, the heaters can also be operated on extra light fuel oil (above 0°C) or kerosine. If in doubt consult the manufacturer.

Electrics:

Arrange electric cables, switches and control units in the vehicle in such a way that their correct functioning cannot be impaired under normal operating conditions.


Fit the control unit so that it is protected from splash water (from both its own vehicle and preceding ones). Outside installation is thus not permissible. The unit is best arranged in the vehicle interior, with the plugs pointing downward.

Control unit



The pilot light (built into the operating unit) should be within the field of vision of the driver, or at least be visible to him without great effort.

The following cable cross-sections must be observed between battery and heater, in order that the maximum permissible voltage losses in the cables (0.5 at 12 V rated voltage and 1 V at 24 V) are not exceeded.



$$L^+ + L^- < 5 \text{ m} \rightarrow \text{cross-section } 4 \text{ mm}^2$$

$$L^+ + L^- 5 \text{ to } 8 \text{ m} \rightarrow \text{cross-section } 6 \text{ mm}^2$$

If the positive cable is to be connected to the fuse box (e. g. terminal 30), the vehicle's cable too from the battery to the fuse box must be included in the calculation of the total line length, and if necessary redimensioned in accordance with the above.

Smear plug and earth connections with contact protection grease outside the vehicle interior.

Operating unit and heater timer


The operating unit (Cat. No. S. 2) includes the On-Off switch with control feature for the heating capacity, a red light for illumination, and a green operating pilot light.

Two scale discs are supplied with the operating unit.


Scale disc 1 is fitted if operation is exclusively with the operating unit. The operating unit then serves as an On switch and temperature controller.

Scale disc 2 is fitted if a timer is used for actuation. Switch-on is then exclusively with the heater timer, and the temperature is selected with the rotary knob. See wiring diagram for connection.

Remove protective film before assembly.



Permissible clearance for operating button
0,5 to max. 1. mm.



Temperature control

A temperature sensor is arranged on the intake side inside the heater, and – in conjunction with the controller of the operating unit – switches the heater to "High", "Medium" or "Low" depending on the intake temperature and the controller setting.

This arrangement of the temperature sensor is only suitable in recirculated-air operation (heating air intake from the area being heated).


If the heater is operated with fresh air (heating air intake from the outside), the built-in temperature sensor must be disconnected, and an external temperature sensor (Cat. No. 25 1774 89 03 00) must be fitted in the interior.

The sensor must not be attached to uninsulated outer panels, and must be protected from draughts and direct sunlight. See wiring diagram for connection.

Important:

On/Off-regulation of the heating capacity using an additional thermostat is not permitted, as it puts an unduly heavy strain on the battery.

Wiring diagram



Parts List

- 1.1 Burner motor
- 1.2 Glow plug
- 1.5 Safety thermal cutout switch
- 1.7 PCB with controller temperature sensor, speed regulator and plug distributor
- 1.12 Flame monitor
- 1.13 Temperature sensor

- 2.1 Control unit
 - 2.2 Fuel metering pump
 - 2.5.1 Current regulator
 - 2.7 Main fuse (25 A)
- 3.1.12 Fault code enquiry (garage)
- 5.1 Battery


- e) to connect the temperature sensor, detach the receptacle housing provided and fit the receptacle housing of the temperature sensor instead.

- g) Connection control elements to heater

Plug housing and socket housing shown from the side where line enters.

25 1830 00 96 01

Wiring diagram



25 1822 00 97 01 C

Parts List

2.15.9 Sensor, external temperature

3.1.11 Operating unit

3.1.12 Fault code enquiry (garage)

3.1.13 Operating unit

3.1.14 Operating unit

3.2.5 Timer

3.2.6 Timer

3.2.7 Timer

3.6.1 Cable harness for 3.1.11

3.6.2 Cable harness for 3.1.13

3.6.3 Cable harness for 3.1.14

3.6.4 Cable harness for 3.2.7

3.8.1 Timer relay

a) Test (garage) digital timer

b) to terminal 15

c) lighting terminal 58

d) break line here to connector timer

f) 3.2.5 / 3.2.6 / 3.2.7 to be connected here

g) Connection control elements to heater

h) Remove S 3 and fit S 2

Function description

Control elements

1. Operating unit
(Cat. No. see page 2).
2. Heater timer (Cat. No. see page 2). The heater can be switched on at once using the timers, or they can be used to preset the switch-on time (24 hours to 7 days depending on version).

Mode of operation

Procedure after starting, normal start.

Switch-on	Green pilot light in the operating unit "on".
After 3 secs.:	Blower "On" at full speed. Heater coil of glow plug "On".

After 40 to 70 secs.:	Fuel conveying "On".
-----------------------	----------------------

When stable flame has been obtained:	Glow plug off.
--------------------------------------	----------------

The heater now operates at full heating capacity (1800 W), and the hot air heated at the heat exchanger passes through the air outlet into the room being heated.

Control in heating operation

Once the intake or room temperature set at the operating unit (10° C to 30° C) has been reached, the heater switches to the "LOW" setting and continues to run at low blower motor speed. If the heating capacity in the "LOW" setting is insufficient, the heater switches to the "MEDIUM" setting. The blower continues to run at low speed. In most cases, the LOW – MEDIUM – LOW control sequence at low blower speed will supply the required heat.

If the "MEDIUM" setting is not sufficient, the heater switches back to "HIGH". This again entails full blower speed. If in special cases an even lower heating capacity is required than the heater delivers in the "LOW" control setting, the heater switches to the "OFF" setting, where this control setting has been provided.

The blower continues to run, and this is followed by constant after-ventilation until restart takes place (in recirculated air operation only).

Restart is generally in the "MEDIUM" setting at low blower motor speed.

When the heater is finally switched off, the green pilot light goes out. The blower continues to run to cool it down, and finally shuts down after about 3 minutes.

Controls and safety equipment

The flame is monitored by the flame sensor(7), and the max. permissible temperature by the safety thermal cutout switch (5). Both affect the control unit (20), which shuts down the heater in the event of faults.

1. If the heater fails to ignite within 90 seconds of fuel starting to be pumped, starting is repeated as described. If the heater still fails to ignite after 90 seconds of fuel pumping, fault shutdown takes place.
2. If the flame goes out spontaneously during operation, a restart is first attempted.
If the heater fails to ignite within 90 seconds of fuel pumping, or if it does ignite but goes out again within 10 minutes, fault shutdown takes place.
The heater can be reset by switching it off and then back on again.
3. In the event of overheating the safety thermal cutout switch (5) is operated, the fuel supply is interrupted, and fault shutdown takes place.
If the fault shutdown is due to overheating, the switch-on pilot light (green) in the operating unit flashes at a steady rate. Further fault indication signals can be called using an additional unit – also see Troubleshooting and Repair Manual.
Once the cause of the overheat has been removed, the unit can be restarted by switching it off and then back on again.
4. If the voltage drops below 10.5 or 21 V or rises above 15 or 30 V as the case may be, fault shutdown takes place.
5. If the glow plug is defective and the electric cable to the metering pump is interrupted, the heater will not start.
6. When the heater starts the operation of the blower motor is checked once. If it does not start, the heater reacts as for fault.
During operation, the blower motor is monitored in cyclic manner (every 4 minutes). If the motor speed is below the allowed limit, fault shutdown follows.
7. When the heater is switched off the glow plug is switched on during the delayed shutdown for about 30 seconds (after-glow) to clear the heater of combustion residues.


Please note:

When carrying out electric welding work on the vehicle, disconnect the positive terminal from the battery and earth it in order to protect the control unit.

The heater must always be switched off when the tank is being filled.

The heater must not be operated in garages.

Sectional drawing




PARTS LIST

1 Hot air blower wheel	8 Heat exchanger	15 Exhaust line	F = fresh air
2 PCB with controller temperature sensor	9 Outer casing	16 Fuel metering pump	V = combustion air
3 Combustion air blower wheel	10 Flange seal	17 Fuel strainer	B = fuel
4 Glow plug	11 Fuel line	18 Main fuse, 25 A	W = hot air
5 Safety thermal cutout switch	12 Series resistor for glow plug (for 24 V only)	19 Current regulator	A = exhaust
6 Combustion chamber	13 Blower motor	20 Control unit	
7 Flame monitor	14 Combustion air intake line	21 Operating unit	
		22 Heater timer	

Operation with the actuating unit

- Blue field = Ventilation
- 0 = Off – after switch-off automatic delayed shutoff for cooling down
- Red field = Heating – turning to the right results in higher heat output
- Illuminated field in knob:
- When vehicle lights are on – red display
 - In heating operation – green display (pilot light)
 - In the event of overheating: steady green flashing
 - Flashing signal: — — — — —



Self-help in the event of trouble:

- Non-starting
- Switch off and back on again.
 - Not more than twice.
 - Check fuse.
 - Consult workshop.
- Overheating
- Remove cause (e.g. blockage of hot air ducts).
 - Switch off and back on again.

See “Heater Timer” operating instructions for operation using timer.

The heater must always be switched off when the tank is being filled.

The heater must not be operated in garages.

By fitting an additional unit (see wiring diagram for connection) further diagnostic signals can be called by pushing a

button (1/2 to 2 secs.). Displayed by green LED.

	0	8	16 Sek.
Operation	—————		
Warning over-/undervoltage ¹⁾	— — — — —		
Overvoltage cutout*	—————	—————	—————
Undervoltage cutout ¹⁾	—————	—————	—————
Glow ignition plug break*	—————	—————	—————
Burner motor not turning*	—————	—————	—————
Short-circuit in changeover relay	—————	—————	—————
Safety time exceeded ²⁾	—————	—————	—————
Non-start	—————	—————	—————
Overheat ³⁾	—————	—————	—————
Short-circuit in fuel metering pump*	—————	—————	—————
Temperature sensor defective*	—————	—————	—————
Flame sensor defective*	—————	—————	—————
Flame cutout at “Low” setting ²⁾ , Heater goes out by itself	—————	—————	—————
Flame cutout at “High” setting ²⁾ , Heater goes out by itself	—————	—————	—————
Control unit defektive*	—————	—————	—————

With faults marked * consult the after-sales service.

¹⁾ Charge the battery at undervoltage.

²⁾ Switch off and back on again, but not more than twice.

Then consult the after-sales service.

³⁾ Remove cause of overheat (e.g. blocked heating air ducts). Switch off and back on again.